

WORKSHOP PROBLEM 4

Rigid Element Analysis with RBAR



Objectives:

- Idealize the tube with QUAD4 elements.
- Use RBAR elements to model a “rigid” end.
- Produce a Nastran input file that represents the cylinder.
- Submit the file for analysis in MSC/NASTRAN.
- Find the displacement vectors.



Model Description:

The goal of this example is to maintain a circular cross section at the rigid end of the tube, (using RBAR elements), while applying a torque of 6000 in-lbs about the z-axis of the tube.

Below is a Finite Element representation of the tube. One end of the tube is considered rigid, and the other end is fixed in all translational and rotational degrees of freedom. Table 4.1 contains all the necessary parameters to construct the input file.

Grid Coordinates and Element Connectivities




Table 4.1

Radius	15 in
Thickness	0.125 in
Length	90 in
Elastic Modulus	10E6 lb/in²
Density	0.101 lbs/in³
Poisson's Ratio	0.3
Moment	6000 in-lbs

Suggested Exercise Steps:

- Generate a finite element representation of the cylinder structure. (i.e., The nodes (GRID) and element connectivities (CQUAD4) should be defined manually.)
- Define material (MAT1) and element (PSHELL) properties.
- Create grid point 999 at the center of the rigid end. This point is to serve as the load application point, as well as the connection point for the rigid element.
- Idealize the rigid end with rigid elements (RBAR).
- Apply the fixed boundary constraints (SPC1).
- Apply a static concentrated moment at the center of the top enclosure, grid 999 (MOMENT).
- Prepare the model for linear static analysis (SOL 101).
- Generate an Input file and submit it to the MSC/NASTRAN solver for linear static analysis.
- Review the results, specifically the displacements along the top edges.



1	2	3	4	5	6	7	8	9	10

Exercise Procedure:

1. Users who are not utilizing MSC/PATRAN for generating an input file should go to Step 15, otherwise, proceed to step 2.

2. Create a new database called **prob4.db**.

File/New Database

New Database Name

prob4

OK

In the New Model Preference form set the following:

Tolerance

◆ **Default**

Analysis code:

MSC/NASTRAN

OK

In the next few steps you will create the necessary geometry for the cylinder model.

3. First create a cylindrical coordinate frame.

◆ Geometry

Action:

Create

Object:

Coord

Method:

3Point

Type:

Cylindrical

Coord ID List:

1

Apply

4. Now create a curve.

◆ Geometry

Action:

Create

Object:

Curve

Method:

XYZ

Vector Coordinate List:

Origin Coordinate List:

Change the view to isoview_1 by selecting this icon:



Iso 1 View

5. Create a surface out of the curve you just made.

◆ **Geometry**

Action:

Object:

Method:

Axis:

Total Angle:

Curve List:

Repeat this step a second time to complete the cylinder. This time select the curve *opposite* **Curve 1** which is **Surface 1.2**.

◆ **Geometry**

Action:

Object:


Method:

Axis:

Total Angle:

Curve List:

Figure 4.1-Geometry of Rigid Element



6. Create the Finite Element Model and mesh the surface.

First you will create 5 mesh seeds along the top and bottom edges, **surface 1.3 2.3**, and 5 along the **Curve 1**.

◆ **Finite Elements**

Action:

Create

Object:

Mesh Seed

Type:

Uniform

◆ **Number of Elements**

Number =

5

Curve List:

Curve 1, Surface 1.3 2.3

Apply

Mesh the surface.

◆ **Finite Elements**

<i>Action:</i>	<input type="text" value="Create"/>
<i>Object:</i>	<input type="text" value="Mesh"/>
<i>Type:</i>	<input type="text" value="Surface"/>
<input type="text" value="Node Coordinate Frame..."/>	
<i>Analysis Coordinate Frame:</i>	<input type="text" value="Coord 1"/>
<i>Refer. Coordinate Frame:</i>	<input type="text" value="Coord 1"/>
<input type="text" value="OK"/>	
<i>Surface List:</i>	<input type="text" value="Surface 1, 2"/>
<input type="text" value="Apply"/>	

Equivalence the model so there are no free edges.

◆ **Finite Elements**

<i>Action:</i>	<input type="text" value="Equivalence"/>
<i>Object:</i>	<input type="text" value="All"/>
<i>Method:</i>	<input type="text" value="Tolerance Cube"/>
<input type="text" value="Apply"/>	

7. Now you will create the Material Properties for the plate.

◆ **Materials**

<i>Action:</i>	<input type="text" value="Create"/>
<i>Object:</i>	<input type="text" value="Isotropic"/>
<i>Method:</i>	<input type="text" value="Manual Input"/>
<i>Material Name:</i>	<input type="text" value="mat_1"/>
<input type="text" value="Input Properties ..."/>	
<i>Elastic Modulus =</i>	<input type="text" value="10.0E6"/>
<i>Poisson Ratio =</i>	<input type="text" value="0.3"/>
<i>Density =</i>	<input type="text" value="0.101"/>
<input type="text" value="Apply"/>	

In the *Current Constitutive Models*, you will see **Linear Elastic - [,,,] - [Active]** appeared. Click on **Cancel** to close the form.

Cancel

8. Give the cylinder a thickness using Properties.

◆ **Properties**

Action:

Create

Dimension:

2D

Type:

Shell

Property Set Name:

wall

Input Properties ...

Material Name:

m:mat_1

Thickness:

0.125

OK

Select Members:

Surface 1, 2

Add

Apply


Next you will apply the Load and Boundary Conditions to the model.

9. Fix the right edge from moving through all Degrees of Freedom. To make the screen selection easier change the view to Right View by selecting this icon:



Right Side View

Figure 4.2 - Node Locations



◆ **Loads/BCs**

Action:

Create

Object:

Displacement

Type:

Nodal

New Set Name:

fixed

Input Data...

Translations <T1 T2 T3>

<0, 0, 0>

Rotations <R1 R2 R3>

<0, 0, 0>

Analysis Coordinate Frame:

Coord 1

OK

Select Application Region...

Geometry Filter:

◆ **FEM**

Select Nodes:

Node 1:31:6 43:61:6

(see Fig 4.2)

Add

OK

Apply

10. Next you must create the loading point where the moment will be applied.

◆ **Finite Elements**

Action: **Create**

Object: **Node**

Method: **Edit**

Node ID List: **999**

Analysis Coordinate Frame: **Coord 1**

Refer. Coordinate Frame: **Coord 1**

Associate with Geometry

Node Location List: **[0, 0, 90]**

Apply

11. Create the rigid element.

◆ **Finite Elements**

Action: **Create**

Object: **MPC**

Type: **RBAR**

Define Terms...

Auto Execute

◆ **Create Dependant**

Node List: **Node 6**

You can type the node into the list directly or you can screen select it by changing back to **Isometric View1** and selecting the node on the *left edge* of the model.

Select DOFs by holding the Shift key down while clicking with the left mouse button.

DOFs:

UX
UY
UZ

Apply

◆ **Create Independent**

Node List:

Node 999

DOFs:

UX
UY
UZ
RX
RY
RZ

Apply

Cancel

Apply


Repeat this procedure nine more times replacing the *Dependant Variable Node List* with **Nodes 12, 18, 24, 30, 36, 48, 54, 60, 66**. The DOFs and the independent node shall remain the same.

Change the view to isoview_1 by selecting this icon:



Iso 1 View

Figure 4.3 - Nodal Constraints on the Rigid Element



12. Now you will create the moment.

◆ **Loads/BCs**

Action:

Create

Object:

Force

Type:

Nodal

New Set Name:

applied_moment

Input Data...

Force:

< >

Moment:

< , , 6000 >

Analysis Coordinate Frame:

Coord 0

OK

Select Application Region...

Geometry Filter:

◆ **FEM**

Select Nodes:


Node 999

Add

OK

Apply

Figure 4.4-Force and Displacement Constraints



13. Create a new group for output.

Group/Create...

New Group Name:

output_request

Group Contents:

Add Entity Selection

Entity Selection:

Node 6:36:6 48:66:6

Apply

Cancel

Note: The selection process for the nodes is the same as in *step 11*. Be certain to set the selection menu filter to nodes only.



Also make sure you **exclude Node 999**.

14. Now you are ready to run the analysis.

◆ **Analysis**

<i>Action:</i>	Analyze
<i>Object:</i>	Entire Model
<i>Method:</i>	Analysis Deck
<i>Job Name:</i>	prob4
Solution Type...	
<i>Solution Type:</i>	Linear Static
OK	
Subcase Create...	
<i>Subcase Name:</i>	output_1
<i>Available Load Cases:</i>	Default
Output Request...	
<i>Form Type:</i>	Advanced

Under Output Requests delete both “STRESS” and “SPCFORCES”, then highlight DISPLACEMENT.

<i>Select Group(s)/Set:</i>	output_request
Modify	
OK	
Apply	
Cancel	

Apply

An MSC/NASTRAN input file called **prob4.bdf** will be generated. This process of translating your model into an input file is called the Forward Translation. The Forward Translation is complete when the Heartbeat turns green. MSC/PATRAN Users should proceed to step 16.

Generating an input file for MSC/NASTRAN Users:

MSC/NASTRAN users can generate an input file using the data from table 4.1. The result should be similar to the output below.

15. MSC/NASTRAN Input File: **prob4.bdf**

```
ID SEMINAR, PROB4
SOL 101
TIME 600
CEND
SET 1 = 6,12,18,24,30,36,48,54,60,66
SUBCASE 1
  SPC = 1
  LOAD = 1
  DISPLACEMENT = 1
BEGIN BULK
PSHELL 1 1 .125 1 1
CQUAD4 1 1 1 2 8 7
= *1 = *1 *1 *1 *1
=3
CQUAD4 6 1 7 8 14 13
= *1 = *1 *1 *1 *1
=3
CQUAD4 11 1 13 14 20 19
= *1 = *1 *1 *1 *1
=3
CQUAD4 16 1 19 20 26 25
= *1 = *1 *1 *1 *1
=3
CQUAD4 21 1 25 26 32 31
= *1 = *1 *1 *1 *1
=3
CQUAD4 26 1 31 32 44 43
= *1 = *1 *1 *1 *1
=3
CQUAD4 31 1 43 44 50 49
= *1 = *1 *1 *1 *1
=3
CQUAD4 36 1 49 50 56 55
= *1 = *1 *1 *1 *1
=3
CQUAD4 41 1 55 56 62 61
= *1 = *1 *1 *1 *1
=3
CQUAD4 46 1 61 62 2 1
= *1 = *1 *1 *1 *1
=3
MAT1 1 10.+6 .3 .101
RBAR 51 6 999 123456 123
= *1 *6 ==
=4
RBAR 57 48 999 123456 123
= *1 *6 ==
=2
```

```

GRID      1      1      15.      0.      0.      1
=         *1      =         =         =         *18      =
=4
GRID      7      1      15.      36.      0.      1
=         *1      =         =         =         *18      =
=4
GRID     13      1      15.      72.      0.      1
=         *1      =         =         =         *18      =
=4
GRID     19      1      15.     108.      0.      1
=         *1      =         =         =         *18      =
=4
GRID     25      1      15.     144.      0.      1
=         *1      =         =         =         *18      =
=4
GRID     31      1      15.    -180.      0.      1
=         *1      =         =         =         *18      =
=4
GRID     43      1      15.    -144.      0.      1
=         *1      =         =         =         *18      =
=4
GRID     49      1      15.    -108.      0.      1
=         *1      =         =         =         *18      =
=4
GRID     55      1      15.     -72.      0.      1
=         *1      =         =         =         *18      =
=4
GRID     61      1      15.     -36.      0.      1
=         *1      =         =         =         *18      =
=4
GRID     999      1      0.      0.      90.      1
SPC1      1      123456  1      7      13      19      25      31      +      A
+         A 43      49      55      61
MOMENT    1      999      0      6000.  0.      0.      1.
CORD2C    1      0.      0.      0.      0.      0.      0.      1.      +      B
+         B 1.      0.      0.
ENDDATA

```

Submit the input file for analysis

16. Submit the input file to MSC/NASTRAN for analysis.
 - 16a. To submit the MSC/PATRAN **.bdf** file for analysis, find an available UNIX shell window. At the command prompt enter: **nastran prob4.bdf scr=yes**. Monitor the run using the UNIX **ps** command.
 - 16b. To submit the MSC/NASTRAN **.dat** file for analysis, find an available UNIX shell window. At the command prompt enter: **nastran prob4 scr=yes**. Monitor the run using the UNIX **ps** command.
17. When the run is completed, edit the **prob4.f06** file and search for the word **FATAL**. If no matches exist, search for the word **WARNING**. Determine whether existing **WARNING** messages indicate modeling errors.
18. While still editing **prob4.f06**, search for the word:

D I S P L A C E M E N T (spaces are necessary)

T2 (GRID 6) = _____

T2 (GRID 30) = _____

T2 (GRID 60) = _____

Comparison of Results:

19. Compare the results obtained in the **.f06** file with the results on the following page:

D I S P L A C E M E N T V E C T O R

POINT ID.	TYPE	T1	T2	T3	R1	R2	R3
6	G	6.489201E-18	8.929722E-04	-7.888723E-19	-1.846752E-05	-1.016440E-20	5.934382E-05
12	G	5.928149E-18	8.929722E-04	-7.324192E-19	-1.846752E-05	7.257694E-20	5.934382E-05
18	G	3.102745E-18	8.929722E-04	-3.383081E-19	-1.846752E-05	2.849946E-19	5.934382E-05
24	G	-9.078021E-19	8.929722E-04	2.429239E-19	-1.846752E-05	-4.996487E-19	5.934382E-05
30	G	-4.571600E-18	8.929722E-04	7.892660E-19	-1.846752E-05	6.445572E-20	5.934382E-05
36	G	-6.489201E-18	8.929722E-04	1.092034E-18	-1.846752E-05	-1.334018E-19	5.934382E-05
48	G	-5.928149E-18	8.929722E-04	1.035581E-18	-1.846752E-05	9.133200E-20	5.934382E-05
54	G	-3.102745E-18	8.929722E-04	6.414700E-19	-1.846752E-05	2.467077E-19	5.934382E-05
60	G	9.078021E-19	8.929722E-04	6.023794E-20	-1.846752E-05	-2.297201E-19	5.934382E-05
66	G	4.571600E-18	8.929722E-04	-4.861042E-19	-1.846752E-05	4.177066E-20	5.934382E-05

20. MSC/NASTRAN Users have finished this exercise. MSC/PATRAN Users should proceed to the next step.

21. Proceed with the Reverse Translation process, that is importing the **prob4.op2** results file into MSC/PATRAN. To do this, return to the Analysis form and proceed as follows:

◆ **Analysis**

<i>Action:</i>	<input type="text" value="Read Output2"/>
<i>Object:</i>	<input type="text" value="Result Entities"/>
<i>Method:</i>	<input type="text" value="Translate"/>
<input type="text" value="Select Results File..."/>	
<i>Selected Results File:</i>	<input type="text" value="prob4.op2"/>
<input type="text" value="OK"/>	
<input type="text" value="Apply"/>	

Set the **default_group** to current.

Group/Set Current...

<i>Set Current Group:</i>	<input type="text" value="default_group"/>
<input type="text" value="Cancel"/>	

22. When the translation is complete bring up the **Results** form.

◆ **Results**

<i>Action:</i>	<input type="text" value="Create"/>
<i>Object:</i>	<input type="text" value="Fringe"/>
<i>Select Result Cases:</i>	<input type="text" value="Default, Static Subcase"/>
<i>Select Fringe Result:</i>	<input type="text" value="Displacement, Translational"/>
<i>Quantity:</i>	<input type="text" value="Magnitude"/>

To change the target entities of the plot, click on the **Target Entities** icon.



Target Entities

Target Entity:

Groups

Select Groups:

default_group

To change the display attributes of the plot, click on the **Display Attributes** icon.



Display Attributes

Style:

Continuous

Element Shrink Factor:

0.05

Apply

22a. Next add the deformation options to the plot.

◆ Results

Action:

Create

Object:

Deformation

Select Result Case(s):

Default, Static Subcase

Select Deformation Result:

Displacements, Translational

Show As:

Resultant

To change the target entities of the plot, click on the **Target Entities** icon.



Target Entities

Target Entity:

Groups

Select Groups:

default_group

To change the display attributes of the plot, click on the **Display Attributes** icon.



Display Attributes

■ **Show Undeformed**

Line Style:



Apply

You may reset the graphics if you click on this icon:



Reset Graphics

You can go back and select any *Results Case*, *Fringe Results* or *Deformation Results* you are interested in.

Quit MSC/PATRAN when you are finished with this exercise.

